



瑞瑪企業有限公司

新北市221汐止區新台五路一段81號4樓之6

TEL: +886-2-2698 0575(Rep)

Website: <http://www.franmar.com.tw>

**FranMar International Inc.**

4F-6, No.81, Sec 1, Xintai 5th Rd., Xizhi Dist., New Taipei City 221, Taiwan

FAX: +886-2-2698 0585

Email: [info@franmar.com.tw](mailto:info@franmar.com.tw)

## **Installation Manual and Safety Instructions**

The following safety precautions must be observed during all phases of operation to avoid injury and prevent damage to the adapter.

### **For power supply models : FRA & FRM**

◎ Type : Wall-mount 、 interchangeable and desktop

◎ Installation :

- (a) Avoid pulling on the AC cords and DC cables. Always grip DC plugs firmly when unplug from power source and when disconnect cables.
- (b) Before attaching the DC plug to the equipment, be sure unplugging the adapter from the AC main power and verify the unit is within the voltage and current rating on the equipment.
- (c) Keep the linkage between the adapter and its power cord tightly as well as connecting the DC plug to equipment properly.
- (d) To ensure adequate cooling of the adapter, be sure that there is at least 10-15 cm clearance around the adapter.
- (e) Disconnect the equipment from the adapter to avoid damage by voltage peaks or lightning strike when final equipment will not use for a long time.
- (f) Make sure power cord will not being trodden on or squashed.



瑞瑪企業有限公司

新北市221汐止區新台五路一段81號4樓之6

TEL: +886-2-2698 0575(Rep)

Website: <http://www.franmar.com.tw>

**FranMar International Inc.**

4F-6, No.81, Sec 1, Xintai 5th Rd., Xizhi Dist., New Taipei City 221, Taiwan

FAX: +886-2-2698 0585

Email: [info@franmar.com.tw](mailto:info@franmar.com.tw)



© Warning :

- (1) To avoid electric shock or fire hazard, do not apply a voltage to a terminal that is outside the range specified for that terminal.
- (2) To avoid electric shock or hazard, do not remove the cover when operate the adapter ; serious result include death form exposure to high voltage. And also be sure to unplug the adapter from its external power source before attaching the power tip.
- (3) Do not operate the adapter in extreme humidity (>90%) or near the water.
- (4) For indoor use only. Avoid exposure to heat source, place in direct sunlight or near fire.
- (5) Do not drop or subject the adapter to undue shock.
- (6) Do not place any heavy object on the top of adapter.
- (7) Before clean the adapter, please disconnect it from AC power and only use slightly damp cloth to clean the adapter.

**Manufacturer :**

FranMar International Inc.

4F-6, No. 8, Sec. 1., XinTai 5<sup>th</sup> Road,

Xizhi Dist., New Taipei City 221, Taiwan

Web: [www.franmar.com.tw](http://www.franmar.com.tw) TEL: +886-2-2698-0575

**Factory Site :**

Youngear Electronics (Dongguan) Co., Ltd.

No. 17 Poling Commercial Street, Qingxi Town

Dongguan City, Guangdong Province, China